



Needlepunch Broadloom Carpet Rolls

Installation, Maintenance, & Warranty
for Roll Goods

Indoors or Vestibules or Other Enclosed Areas:

OPTIONS

1. Loose-lay where temporary use is dictated.
2. Loose-lay in recess where frequent mat changes are encouraged.
3. Double-face tape, in areas where semi-permanent use is dictated.
4. Permanent installation method:
 - Use NA Carpet Lock Super Adhesive (Covers 288-1,000 s/f per 4 gallon) or comparable adhesive **. Apply w 3/32 sq notch trowel over smooth, moderately porous subfloor. If subfloor is smooth yet highly porous, seal with 1 or 2 coats of Uniseal Sys FLOOREVERDRI to seal porosity of subfloor. Allow to dry/ set 1-2 hours before troweling Adhesive. (dry-to-touch time is dependent on porosity of subfloor, temp and humidity - 1 coat is generally dry to touch in 30 minutes...2 coats FloorEverDri is ready to install over in 60-90 minutes...when 2nd coat is dry to touch).
 - Allow adhesive to tack-up but not skin over
 - Roll with a 75-100 lb roller.
 - Cut seam net, apply no seam sealer. Minimize use of head seams for best visual appearance.
 - Disallow unprotected foot traffic and all rolling traffic for 12 hours, and disallow unprotected heavy foot / rolling traffic for 48-72 hours.
 - Keep area completely dry for 72 hours.

** If area is subject to extreme temp changes, use NA Everbond Super Adhesive.

Outdoors:

OPTIONS

1. Loose-lay in framed or unframed areas where temporary use is dictated.
2. Permanent installation:

If sub-surface is rough or highly porous use appropriate cementacious outdoor-rated product to achieve desire smooth, slightly porous surface. Allow adequate time to cure / dry before going forward with installation.

 - Use product an outdoor, water-based solvent Adhesive w 3/32 sq notch trowel over smooth moderately porous subfloor.
 - Follow temperature and acclimation criteria as outlined by the Adhesive Manufacturer
 - Allow adhesive to tack-up.
 - Roll with a 75-100 lb roller.
 - Cut seams net, apply no seam sealer. Minimize use of head seams for best visual appearance.
 - Protect from elements until adhesive is cured. Follow all directions on adhesive label.
 - Disallow unprotected foot traffic and all rolling traffic for 12 hours, and disallow unprotected heavy foot / rolling traffic for 48-72 hours.

Maintenance: Vacuuming, extraction, and shampooing

Warranties*: Five (5) years on smooth flat surfaces. Three (3) years on flat surfaces under cleat and spike traffic.

**See Fordom warranty terms*